

Selfie Ring Light with Tablet Holder

Specifications

Input Rating: 5V d.c. 2A 10W

LED Light Source Output: 830lm

LED Light Source Colour Temperature: 3000-6500K

LED Light Source Current: 1.8A

LED Light L70B50 Lifetime: 30,000 h

LED Light Source On-mode Power: 9W

LED Light Source Colour Rendering: >80

LED Ring Dimensions: 27 x 27 x 2.1 cm

Max Stand Height: 220cm

This product contains a light source of energy efficiency class F.

Safety Instructions

- Do not look directly into the LEDs when operating
- LED light output is strong enough to injure human eyes. Precautions must be taken to prevent looking directly at the LEDs for more than a few seconds
- Long-life LED lights are not replaceable
- For indoor use only
- Keep away from liquids, oils, petrol, and all chemicals
- Do not expose to heat sources
- The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed
- If the lighting fixture is damaged, it should be exclusively replaced by the manufacturer or the service agent or qualified person in order to avoid a hazard
- Never add any attachments and/or equipment without the approval of the manufacturer
- Unauthorised modifications may result in fire, electric shock or other personal injury and void your warranty
- Keep away from children
- Supervise young children to ensure they do not play with the product
- The luminaire is not suitable for mounting on tubular material.
- The product shall be supplied by a external independent LED driver with at least 5V, 2A SELV output.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced
- **WARNING:** The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed
- **WARNING:** This product is only intended for use as selfie light, image capturing purpose
- **WARNING:** This product is not suitable for household room illumination

Product Overview

1. Ring light
2. Phone holder*
3. Side cog
4. Back cog
5. Top wing nut
6. Bottom wing nut
7. Tripod wing nut
8. Light controller
9. Tablet holder
10. Tablet ball and socket joint

*Phone not included



This product fulfils the European directives 2011/65/EU and 2014/30/EU.



Compliance with the WEEE Directive and disposal of waste products. This product has been made from high-quality parts and materials which can be reused and are suitable for recycling. Therefore, do not dispose of the product with normal household waste at the end of its service life. Take it to a collection point for the recycling of electrical and electronic equipment. This is indicated by this symbol on the product, in the operating manual and on the packaging. Please consult your local authorities to find out where the nearest collection point is. Help protect the environment by recycling used products.



Packaging materials of the product are manufactured from recyclable materials in accordance with our National Environment Regulations. Do not dispose of the packaging materials together with the domestic or other wastes. Take them to the packaging material collection points designated by the local authorities.

Using the Selfie Ring Light with Tablet Holder

Assembling your selfie ring light

1. Loosen the tripod wing nut that is located at the top of the tripod, pull out the legs of the tripod to your desired position and tighten the tripod wing nut again.

Please note: The tripod can be adjusted again at any time. If the tripod is not in your ideal position, it can be changed by loosening the tripod wing nut and moving the legs into your desired position.

2. Loosen the back cog on the tripod. Place on the top of the tripod and tighten the back cog until it is as tight as you can get it.



3. Unscrew the side cog on the ring light until you can pull the side cog all the way out. Insert the bottom of the ring light into the tripod light connector. Insert the side cog pin back through the hole. This will lock the ring light with the tripod connector



4. Undo the socket at the back of the tablet holder so that the parts inside are as loose as possible but do not remove the socket completely. Put the ball in the socket and tighten.



5. Once the tablet ball and socket are connected unclip the wire at the back of the tablet mount and open the clasp. Attached the clasp to the top pole of the tripod and reclip the wire. This is locked into place by the clip at the back.

Mount your smartphone by securing it in the phone holder

Pull each end of the phone holder to extend. Carefully place your phone between each side of the holder. Your phone should be firmly secured


Please note: You will not need to remove your phone case

Mount your tablet by securing it in the tablet holder

Pull each end of the tablet holder to extend. Carefully place your tablet between each side of the holder. Your tablet should be firmly secured

Please note: We recommend this tablet holder for use with tablets no larger than 10.2-inch screen

Lighting mode

Plug the USB into either a power adaptor (not supplied) or a computer/laptop (not supplied). Then press the power button on the control panel. On the control panel you can adjust the brightness of the LED selfie light by pressing the + to increase the brightness or the - to decrease the brightness. There are 10 levels for you to choose from. You can also change the colour of the white by pressing the  button. There are three whites to choose from (these range from cold to warm white)



Position the selfie stand to your desired height and angle

You can move the light by unscrewing the side cog, this will allow you to adjust the angle of the light. Move the light to the position that suits you, then retighten the cog. You can adjust the height of the tripod by unscrewing either or both of wing nuts on the pole and extending the pole to the position that suits you best. You can also adjust the angle of the phone holder by moving the arm of the phone holder.

Once you are happy with the look, simply smile and start.

HE210248

Product code: 717326

12/2021

After Sales Support

Phone: 44 800 496 9698

Email: customercare@balcolifestyle.com