

JORJ

Wax Heater

User Guide



Important Safety Warnings

- Read all the instructions before using the wax warmer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep it out of reach of children and pets.
- DO NOT place or store the device where it can fall or be pulled into a tub or sinkhole.
- DO NOT place the wax warmer into water or any liquid; keep the surrounding area dry.
- Keep the appliance and power cable away from heat sources and hot surfaces.
- Always protect the power cable from undue flexing and wearing – do not allow the cable to hang off edge of the counter or table.
- DO NOT use this appliance with an external timer or separate remote-control system of any kind.
- CAUTION: DO NOT operate the appliance on an inclined plane. DO NOT operate the appliance unless the element is fully immersed. DO NOT move the appliance while it is switched on.
- Avoid placing or storing the appliance where it may contact water.
- This appliance is intended for indoor use only.
- Do not operate the appliance if the power cord or plug is damaged.
- Never immerse the appliance in water or any other liquid.
- Do not overflow the pot.
- Do not leave the appliance unattended when in use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not touch the heating element when the appliance is in use.
- Do not cover the appliance while it is in operation.
- Keep the wax warmer away from flammable materials.
- Only use the appliance with the recommended wax products.
- If the appliance falls into any water or liquid, DO NOT reach into the water. Unplug the device immediately with caution.
- Take caution when pouring hot wax. Pour slowly. DO NOT over-fill the appliance.
- The appliance remains a scalding hazard long after the wax has melted.
- The appliance heating element surface is subject to residual heat after use.
- To ensure your skin is not overly sensitive to the wax, test it first with a small amount of wax on the skin.
- Before applying, measure the wax temperature with a thermometer.
- Avoid waxing any wounded area.
- Alcohol and water are not suitable for cleaning the residual wax on the skin.
- Avoid contact with moisture, such as hot showers or steam rooms, for 24 hours after waxing.
- Do not use the wax if your skin has experienced any adverse reaction to wax in the past.
- If you are on medication that affects the skin or have a skin-related disorder, consult your doctor before using.
- Unplug the appliance before cleaning.
- Do not attempt to repair, open, or alter any components of the appliance. In the case of improper usage or if you have opened, altered, and repaired the product yourself, all guarantees are void.
- Do not use the appliance for other than intended or specified purposes.
- The supplier is not responsible for the end use of this product including any improper use or when used for purposes that are not specified.
- WARNING: Do not use this appliance in a bathtub, shower, or water filled reservoir
- Only use the wax beads recommended by the manufacturer
- Maximum wax bead loading is 400ml, minimum loading is 10ml
- Disposal the used wax according to local regulations
- The maximum temperature the melted wax could reach is 100°C.

Specifications

Product Name: Wax Warmer (Electronic)

Model No.: BE0055

Product size: 182mm x 195mm x 141mm

Voltage: AC 220-240V

Power: 100W

Capacity: 400mL

Temperature Range: 30-125°C

Standard: Appliance Class I

Temperature Control Mode: NTC automatic temperature control

Introduction

Thank you for choosing our JORJ Electrical Wax Heater Appliance. This manual is designed to provide you with important information on how to use your wax warmer safely and effectively. Please read this manual thoroughly before using the appliance to ensure your safety and the best results.

Package Contents

Your package should include the following items:

1. Wax Heater Base Unit
2. Removable aluminium wax pot
3. Transparent lid for wax pot
4. Spatula storage space
5. Power cord
6. User manual (Not shown)



Getting Started

1. **Power:** Lightly touch the **⏻** button to turn on the wax warmer - the buttons and logo will light up and display 87°C as the default temperature. If left at 87°C without touching any other buttons, the monitor will slowly warm up to the chosen temperature.
2. **Change temperature:** Press the **⊕** and **⊖** to increase or decrease the temperature of the wax heater. After the desired temperature is set, wait for a few seconds, and the device will start to warm up to the temperature selected.
3. **Timer mode:** Press **⌚** to start timer mode. After timer mode is selected, the length of time can be adjusted using the **⊕** / **⊖** buttons. The default timer is set at 30 minutes. The range chosen can be between 1-90 minutes.

To achieve the optimal time, you can adjust the time according to wax quantity.

Suggested Wax Times

Wax Quantity	Time	Temperature
100g	17 minutes	87°C
200g	35 minutes	87°C
300g	45 minutes	87°C

4. **Appointment mode:** Continually press the **⌚** to start appointment mode. The monitor will show H: 01 to indicate you are in appointment mode. Press **⊕** / **⊖** to increase and decrease the time, H:01 indicates 1 hour. The longest time appointment can be up to 24 hours. The wax warmer will start heating after countdown finishes.
5. **Heating Safety Mode:** To avoid overheating, after 30 minutes of continual use, the the heater will re-set to 87°C

Notes

1. Always perform a small test patch to your skin to check for any allergic reactions.
2. Only apply a small amount of wax to the skin to test the wax temperature.
3. Avoid using wax on wounded areas.
4. Do not use wax if your skin has suffered any adverse reactions to wax in the past.
5. Do not use wax within two hours of taking a shower or sunbathing.
6. Consult with a doctor before undergoing a wax treatment if you currently are on medication that may affect the skin or if you have a skin related condition.

Cleaning and Maintenance

- Always unplug the appliance and allow it to cool before cleaning.
- Remove any remaining wax from the wax pot using a spatula.
- Wipe the interior and exterior of the wax pot with a clean, dry cloth.
- The wax pot and lid may be hand washed with mild soap and warm water.
- Ensure the appliance is completely dry before using it again.